# Battery Pack—All Ceiling Types

Installation Steps

1 Prepare Fixture

1. Remove WAC and pull wiring harnesses out until connectors are visible.

2. Disconnect the 2-pin DC connector and insert battery pack extension as highlighted in the wiring diagram.

Battery Pack Extension Harness

TO LED

2pin DC connector

driver

2 Continue Installation

1. Continue to follow Interspace instructions to complete installation of fixture run.

2. Continue to follow battery pack instructions to complete installation of remote test button.